



# CLEANING AND MAINTAINING YOUR PPE



## Clean It!

### Disassemble



Disassemble as per the user instructions

### Disinfect



Disinfect after use the PPE with the recommended solution. Leave solution for a minimum of 30 seconds.

### Rinse



If using a diluted disinfection solution remove by wiping with a clean cloth dampened with fresh water.



## Dry It!

### Dry



We recommend that you leave the product to air dry after disinfection for a minimum period of 6 hours.

### Reassemble



Reassemble as per the user instructions



## Inspect It!

All PPE should be inspected daily by the wearer for excess wear or damage, such as dents, cracks, scratches and penetration.

Any worn, damaged, or defective parts should be removed from service and replaced.

Please note that any safety helmet that sustains an impact should be replaced even with no noted signs of damage.

### Our Top PPE Recommended Checks

- ✓ Check for deep scuffs or scratches
- ✓ Check it is in general good condition
- ✓ Do not put any unchecked stickers or pen
- ✓ Check your PPE is CE marked
- ✓ Check your date of manufacturer and start of use date
- ✓ Do not throw your PPE around
- ✓ When not being used place in a bag or store somewhere safe
- ✓ Do not wear any unlicensed headwear underneath your helmet

Regularly scheduled maintenance sessions with your PPE make all the difference.

Visit [centurionsafety.eu](http://centurionsafety.eu) for further information



**CENTURION**  
WHEN CLARITY COUNTS