

CLEANING AND MAINTAINING YOUR PPE





Disassemble as per the user instructions



Disinfect the PPE after use with the recommended solution. Leave solution for a minimum of 30 seconds.



If using a diluted disinfection solution remove by wiping with a clean cloth dampened with fresh water.





We recommend that you leave the product to air dry after disinfection for a minimum period of 6 hours.



All PPE should be inspected daily by the wearer for excess wear or damage, such as dents, cracks, scratches and penetration.

Any worn, damaged, or defective parts should be removed from service and replaced.

Please note that any safety helmet that sustains an impact should be replaced even with no noted signs of damage.

Regularly scheduled maintenance sessions with your PPE make all the difference.

Visit centurionsafety.eu for further information

Our Top PPE Recommended Checks

- ✓ Check for deep scuffs or scratches
- \checkmark Check it is in general good condition
- $\checkmark~$ Do not put any unchecked stickers or pen
- ✓ Check your PPE is CE marked

Reassemble as per the user instructions

- Check your date of manufacturer and start of use date
- \checkmark Do not throw your PPE around
- ✓ When not being used place in a bag or store somewhere safe
- ✓ Do not wear any unlicensed headwear underneath your helmet

